

Winterizing your outdoor shower

In areas prone to heavy frost, you are required to drain the internal lines of your outdoor shower before the first freeze or after each use if using throughout to prevent the expansion of water from damaging the internal valves. Outdoor showers must be completely winterised to prevent catastrophic freeze damage to internal valves, pipework, and mixing chambers. Because these units are engineered for warm climates, standing water inside the components expands when frozen, cracking the metal or plastic housing.

Please these follow the below instructions:

- **Turn off/ isolate the water supply** leading to the outdoor shower.
- **Open all taps and valves** completely to allow trapped air and water to move.
- **Disconnect all hoses and attachments** including the cigar hand piece and hose.
- **Blow out remaining water** using a compressor or a wet/dry vacuum if the unit cannot be uninstalled.
- **Bring the unit indoors** for the winter season, by undoing the three Allen grub screws to release the shower tower and store indoors.
- **Wrap with insulation** and a waterproof cover if the shower is permanently fixed outdoors.

Waterware have protective bags available (FWODBAG - Pacific outdoor protective bag)

