

WATERWARE

Flow Regulated Aerator Insert

WSA Instructions

To fit 'standard' M22 aerator housings.



Orange = 5L/min

Green = 7L/min

Unscrew the existing aerator housing and place the flow regulated aerator into the housing followed by either the thin washer for female housings or the thick washer for male housings. Reassemble the aerator housing to the spout without over tightening and check for a good seal.

PH 09 273 9191 | info@waterware.co.nz

PO Box 58 776 Botany, Manukau

waterware.co.nz